




Specifications

Uplink frequency	880-915 MHz, 1710-1785 MHz	Downlink frequency	925-960 MHz, 1805-1880 MHz
Indoor coverage	300 m ²	Impedance	50 Ω
VSWR	≤ 2.0	I/O Ports	N Female
Uplink Gain	65 dB	Power Supply	AC 100-240V to DC 12V/5A
Downlink Gain	65 dB	Operating t °C	-25 / +55
Output Power	≥ 13 dBm	Operating Humidity	5 - 95 % Noncondensing
Manual Gain Control	≥ 31 dB / 1 dB step	IP Rating	IP40
Automatic Level Control	≥ 15 dB	Dimensions	255*170*35mm
Automatic Shut Off	after 15 dB	Weight	1.53 kg

Package



Spears 300 V4G-H



Power supply



User manual

 Calls/GSM/4G/LTE

 Free Support

 Conformity to CE and RoHS standards

 Coverage: 300 m²

 3-year warranty & service

 3-7 business day delivery

 Freq.: 900, 1800 MHz

 30-day return policy

Need Help?

support@rangeiful.com
+371 25 444 666

Product description

Spear 300 V4G-H is the most advanced mobile repeater that strengthens weak GSM and 4G LTE signals at 2 frequencies.

Coverage area

Spear 300 V4G-H amplifies signals in premises and areas of up to **300 m² (3200 ft²)**.

Signal types supported

The 2-band booster is used to amplify mobile signals at 2 frequencies: calls at 900 and 1800 MHz, LTE signals at 1800 MHz.

- 900 MHz is the most commonly used frequency in the European Union and worldwide. 1800 MHz is a sub frequency, although it is considered the main frequency in some regions. This model is best for users operating at both GSM frequencies.
- The one of most-used bands in LTE networks is 1800 MHz (Band 3), which is a mainstream choice for LTE in most regions.

Benefits and features


The Spear 300 V4G-H amplifier is efficient and easy to use and has the following features:

- LCD displays signal strength, settings, recommendations and error notifications.
- Sleep mode to save energy and money. The booster will automatically enter sleep mode when there are no incoming and outgoing calls or data.
- The amplifier automatically detects and adjusts the input signal.
- Compact, laconic design, lightweight, and high-tech LCD screen.
- The amplifier provides stable signal of GPRS and EDGE network, as well as LTE of the most operators.

Need Help?

support@rangeful.com
+371 25 444 666

Installation guide



1. Find an appropriate position for an outdoor antenna.
2. Connect the outdoor antenna to the repeater to the "Outdoor" connector and fasten tightly.
3. Connect the indoor antenna to the repeater from "Indoor" side and fasten tightly.
4. Connect the power supply to the repeater.
5. Switch on the repeater. If the Power LED on the repeater turns on it means the installation has been implemented correctly.
6. Test the signal of your mobile telephone – a maximum quantity of bars should be indicated on the display of your phone in each corner of the location within repeater coverage zone. In case the mobile signal is still unstable try to change the position of the outdoor antenna for more proper one.

Need Help?

support@rangeful.com
+371 25 444 666